



## Seismic Isolator Placement Alternates 1, 2, 3

Seismic Isolators  
Located in Sub-basement



Seismic Isolators  
Located at Top of Basement Columns



Seismic Isolators  
Located at Mid-height of Basement Columns

